



ROTEM
a Munters company

Каталог оборудования Rotem-2021

Артикул	Наименование
<i>Контроллеры Platinum</i>	
11-900-08-10095	Platinum Touch 50-POU-EN-MUR-30A
11-900-12-00011	Platinum Pro 30-POU-EN-MUN-30A
11-900-12-10011	Platinum Pro 30-POU-EN-MUR-30A
11-900-12-10120	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10122	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10123	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10124	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10128	Platinum PRO 30-POU-JA-MUR-30A
11-900-12-10136	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10148	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10156	Platinum PRO 30-POU-CH-MUR
11-900-12-10180	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10190	Platinum Pro 30-POU-PL-MUR-30A
11-900-12-10193	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10198	Platinum Pro 30-POU-CH-MUR-30A
11-900-12-10211	Platinum Pro 30-POU-LYR-RU-MUR-30A
11-900-12-10240	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10241	Platinum Pro 30-POU-LYR-MUR-30A
11-900-12-10243	Platinum Pro 30-POU-LYR-RU-MUR-30A



11-900-12-10257	Platinum Pro 30-POU-LYR-RU-MUR-30A
11-900-12-10259	Platinum Pro 30-POU-LYR-CH-MUR-30A
11-900-12-10268	Platinum Pro 30-POU-CH-MUR-30A
11-900-12-10273	Platinum Pro 30-POU-LYR-CH-MUR-30A
11-900-12-10274	Platinum Pro 30-POU-LYR-CH-MUR-30A
11-900-12-10279	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10281	Platinum Pro 30-POU-PL-MUR-30A
11-900-12-10283	Platinum Pro 30-POU-RU-MUR-30A
11-900-12-10284	Platinum Pro 30-POU-LYR-RU-MUR-30A
11-900-15-10005	Platinum Touch 30-POU-EN-MUR-30A
11-900-15-10128	M Touch 30-POU-EN-MUR-30A
11-900-15-10136	M Touch 30-POU-EN-MUR-30A
<i>Контроллеры Pro</i>	
11-900-18-10011	Rotem Pro-POU-EN-MUR-30A
11-900-18-10136	Rotem Pro-POU-RU-MUR-30A
11-900-18-10165	Rotem Pro-POU-RU-MUR-30A
11-900-18-10177	Rotem PRO-POU-RU-MUR-30A
11-900-18-10203	Rotem Pro-POU-EN-MUR-30A
11-900-18-10260	Rotem Pro-POU-PL-MUR-30A
11-900-18-10265	Rotem Pro-POU-RU-MUR-HS-30A
11-900-18-10291	Rotem Pro-POU-PL-MUR-30A
11-900-19-10011	Rotem ONE-POU-EN-MUR-30A
11-900-19-10020	Rotem ONE-POU-EN-MUR-30A
11-900-19-10233	Rotem ONE-POU-RU-MUR-30A
<i>Контроллеры AC 2000</i>	
11-901-01-10036	AC2000 3G-POU-BRO-EN-MUR-UN-2TS
11-901-01-10055	AC2000 3G-POU-BRO-RU-MUR-UN-232
11-901-01-10070	AC2000 3G-POU-BRO-RU-MUR-UN-2TS
11-901-01-10071	AC2000 3G-POU-BRO-RU-MUR-UN-232
11-901-01-10087	AC2000 3G-POU-BRO-RU-MUR-UN-SP
11-901-01-10114	AC2000 3G-POU-BRO-PL-MUR-UN-2TS



11-901-01-10155	AC2000 3G-POU-BRO-RU-MUR-UN-SP
11-901-01-10158	AC2000 3G-POU-BRO-RU-MUR-UN-SP
11-901-01-10159	AC2000 3G-POU-BRO-RU-MUR-UN-485-SP-4TS-RH1
11-901-01-10164	AC2000 3G-POU-BRO-RU-MUR-UN-485-SP-5TS-RH1
11-901-02-10007	AC2000 PL-POU-BRO-EN-MUR-230V-2TS
11-901-02-10020	AC2000 PL-POU-BRO-PL-MUR-230V-2TS
11-901-02-10098	AC2000 PL-POU-BRO-PL-MUR-230V
11-901-03-10021	AC2000 SE-POU-BRO-RU-MUR-230V-232-2TS
11-901-03-10032	AC2000 SE-POU-BRO-PL-MUR-230V-232-2TS
11-901-03-10079	AC2000 SE-POU-BRO-RU-MUR-230V
11-901-04-00003	Relay Extension BOX-REB-8
11-901-04-10004	Relay Extension Box-REB-8-POU-MUR-230V
<i>Контроллеры Smart</i>	
11-902-01-10025	Smart 8C-VAR-POU-PL-MUR-230V-1TS
11-902-01-10029	Smart 8C-VAR-PIG-EN-MUR-230V-1TS
11-902-01-10031	Smart 8C-VAR-POU-RU-MUR-230V-1TS
11-902-01-10041	Smart 8C-VAR-POU-EN-MUR-230V-1TS
11-902-01-10044	Smart 8C-POU-RU-MUR-230V-1TS
11-902-01-10087	Smart 8C-VAR-PIG-RU-MUR-230V-1TS
11-902-02-10005	Smart 10D-PIG-EN-MUR-UN-1TS
11-902-02-10006	Smart 10D-POU-EN-MUR-UN-1TS
11-902-99-00002	Smart POU- RS485 Card
11-902-99-00034	Smart PIG- RS232 Card
11-903-01-00008	Natural Master-NM-PIG-DK-MUN-10A-NS-230V-1TS
<i>Контроллеры Piguarg и SuperGuard</i>	
11-903-01-10007	Piguarg-80-PIG-EN-MUR-10A-NS-230V-2TS
11-903-01-10008	Natural Master-NM-PIG-DK-MUR-10A
11-903-01-10012	Piguarg-80-PIG-RU-MUR-10A-NS-230V-2TS
11-903-02-00015	Piguarg Plus-80-PIG-RU-AV-30A-CG-230V-2TS
11-903-02-10012	Piguarg PLUS-82-PIG-EN-MUR-30A-230V-2TS
11-903-02-10017	Piguarg Plus-80-PIG-RU-MUR-30A-CG-230V-2TS



11-903-02-10019	Piguard PLUS-82-PIG-RU-MUR-30A-CG-230V-2TS
11-903-02-10043	Piguard Plus-81-PIG-RU-MUR-10A-NS-CG-230V-2TS
11-903-04-10008	Superguard-PIG-RU-MUR-CG-230V
11-903-04-10010	Natural Center-NC2-PIG-DK-MUR-230V-1TS
11-903-05-10007	Superguard PLUS-PIG-RU-MUR-CG-230V
<i>Дистанционное управление и связь</i>	
11-904-07-10016	Commbox-POU-EN-MUR
11-904-07-10017	Commbox-PIG-EN-MUR
11-904-08-10002	Communicator 2-POU-MUR-230V-485W-CMEU
11-904-08-10007	Communicator 2-POU-MUR-230V-485W-CMAU
11-904-08-10010	Communicator 2-POU-MUR-230V-485W-CMEU
11-904-08-10020	Communicator 2-POU-MUR-230V-232W-CMEU
11-905-02-10018	Rlink1-POU-MUR-900-1W-OM-2dBi-485ISO
11-905-02-10034	Rlink1-POU-MUR-900-1W-OM-2dBi-232
<i>Взвешивание корма (в бункере) и птицы</i>	
11-906-01-00016	Scale Center-RSC-2SE-POU-ROT-230V
11-906-01-10004	Scale Center-RSC-2SE-POU-EN-MUR-230V
11-906-01-10016	Scale Center-RSC-2SE-POU-MUR-230V
11-906-01-10021	Scale Center-RSC-2SE-POU-EN-MUR-230V
11-906-01-10022	Scale Center-RSC-2SE-POU-EN-MUR-230V
11-906-01-10026	Scale Center-RSC-2SE-POU-EN-MUR-230V
11-906-01-10030	Scale Center-RSC-2SE-POU-EN-MUR-230V
11-907-01-00001	AC2000SE/3G Scale-RBS-1-POU-Floor Bird Scale
11-907-02-00001	RSC2SE Scale-RBS-2-POU-Floor Bird Scale-FBS-15M
11-907-02-00002	RSC2SE Scale-RBS-2-POU-Floor Bird Scale-FBS-50M
11-908-01-00005	AC2000SE/3G Scale-RBS-1-POU-Hanging Bird Scale-HBS-SE-22M-230V
11-908-02-00003	RSC2SE Scale-RBS-2-POU-Hanging Bird Scale
11-908-02-00005	RSC2SE Scale-RBS-2-POU-Hanging Bird Scale
11-908-02-00006	RSC2SE Scale-RBS-2-POU-Hanging Bird Scale
11-908-03-00005	Platinum Scale-RBS-3-POU-Hanging Bird Scale



11-908-03-00008	Platinum Scale-RBS-3-POU-Hanging Bird Scale
11-909-03-00001	Platinum Scale-RBS-3-POU-Floor Turkey Scale
11-910-03-00002	Platinum Scale-RBS-3-POU-Hanging Turkey Scale
11-910-03-00003	Platinum Scale-RBS-3-POU-Hanging Turkey Scale
11-911-01-10019	Silo Weight-RSW-2-POU-BRO-EN-MUR-230V
11-911-01-10020	Silo Weight-RSW-2-POU-OTH-CH-MUR-230V
11-911-01-10023	Silo Weight-RSW-2-POU-BRO-CH-MUR-230V
11-911-01-10025	Silo Weight-RSW-2-POU-BRO-RU-MUR-230V
11-911-01-10037	Silo Weight-RSW-2-POU-OTH-RU-MUR-230V
11-911-02-00001	Silo Junction Box-RJB4-POU-ROT
11-911-04-00002	Silo Load Cell-RSLC-POU-10-BP
11-911-05-00001	Silo Load Cell-RSLC-POU-25-BP
11-912-01-00001	Feed Scale RFS-6-POU-BRO-DA-MUN-230V
11-912-01-10001	Feed Scale-RFS-6-POU-BRO-DA-MUR-230V
11-912-01-10008	Feed Scale-RFS-6-POU-OTH-EN-MUR-230V
11-912-01-10015	Feed Scale-RFS-6-POU-OTH-EN-MUR-230V
11-913-01-00001	Portable Bird Scale-RPBS-POU-EN-ROT-230V-10K
11-913-02-00003	Portable Bird Scale-RPBS-POU-EN-ROT-230
<i>Датчики и сигнализации</i>	
11-914-01-00002	Water Meter-RWM-POU-MUN-3/4INCH
11-914-01-00003	Water Meter-RWM-POU-ROT-3/4INCH
11-914-02-00002	Water Meter-RWM-POU-ROT-1INCH
11-914-05-00002	Unmeasured Flow Reducer-POU-3/4 BSP
11-915-01-10001	Light Dimmer-RLD-POU-EN-MUR-230V
11-916-03-00001	Emergency Siren Light-ESL-POU-B&C-230V
11-916-03-00002	Emergency Siren Light-ESL-PIG-BC-230V
11-917-02-00003	Humidity Sensor-RHS-POU-ROT-SE-10PL
11-917-02-00004	Humidity Sensor-RHS-POU-MUN-SE-10PL
11-917-02-00005	Humidity Sensor-RHS-PIG-ROT-SE-10PL
11-918-01-00001	Temperature Sensor Black-RTS-2-POU
11-918-01-00002	Temperature Sensor Black-RTS-2-PIG



11-918-02-00001	Temperature Sensor Grey-RTS-1-POU
11-919-01-10002	CO2-POU-EN-MUR
11-920-01-10001	Static Pressure Control-RSP-5-POU-EN-MUR-230V-1TS
11-920-02-00002	Static Pressure Sensor-RPS-1-POU-MUN-230V
11-920-02-10001	Static Pressure Sensor-RPS-1-PIG-MUR-230V
11-921-01-10004	Digital Thermostat-RDT-5-POU-EN-MUR-232EXT-230V
11-922-01-00002	RPLP-POU-ROT-230V
11-922-01-00003	Power Line Protector-RPLP-POU-MUN-230V
11-922-02-00001	RIT50-POU-230V
11-923-01-00001	RCLP-POU
11-926-01-00002	WS-Rain Detection Sensor-RDS-1-POU-230V
11-926-01-00006	WS-Wind Speed & Direction Sensor
11-927-01-00001	Remote Scale Unit-RSU-2-POU-ROT
11-927-01-10001	Remote Scale Unit-RSU-2-POU-MUR
11-927-01-10003	Remote Scale Unit-RSU-2-POU-MUR-PS
11-930-01-00008	Eggcount 50-POL-LYR-MUN

